



How-to change your Vectra B pollen filter

Part of the How-to series produced by VVON.co.uk

Credit to & PDF of original How-to by Leeky.

Disclaimer

The owners of VVON accept no responsibility for any damage to any person or any vehicle by following or using the information contained within this how-to Guide.

This how-to guide covers replacing your pollen filter, and is suitable for every model of the Vectra B.

What to do

1. Allow the engine to cool (so you don't burn your hands)
2. Lift the bonnet up
3. Remove the rubber strip that runs across the plastic scuttle panel at the rear of the engine bay
4. Lift the flap in the plastic scuttle panel to reveal the pollen filter
5. On each side of the pollen filter housing are two tabs; open both of these up
6. Pull out the old pollen filter
7. Clean any big debris from around the area
8. Fit new pollen filter
9. Close both tabs to lock filter in place
10. Close the flap up on the scuttle panel
11. Refit the rubber strip across the bulkhead panel and close your bonnet.



The pollen filter can be seen at the top of the picture above, with the scuttle panel removed to allow for easier identification.